

















#### **Speedwrap Dispenser**

Dispense film, foil and baking parchment with a single press!



Why struggle with the end of cling film rolls and wasted product when Speedwrap stores, protects and dispenses your refill rolls with a simple press of the lid.

Speedwrap (available in both 450mm and 300mm widths) cuts cling film, foil & baking parchment with a single press.

This updated version of our compact catering dispenser is more robust, dishwasher safe and offers one press cutting for all your food wraps time after time.

Speedwrap dispensers could also help to improve your FHR score!

- Available in both 300mm & 450mm widths
- Reduces waste
- One press cutting
- · Compact, light and mobile
- Hygienic could help improve your FHR
- Quick and easy to load
- Features lockable lid & non slip feet
- Competitively priced dispenser refill rolls





### **Speedwrap Dispenser**

**Units & refills** 

Speedwrap 450 professional

#### Speedwrap 300 professional







Fresh cling refills - pack of 3 450mm x 300m



Aluminium foil refills - pack of 3 450mm x 90m



Baking parchment refills- pack of 3 (non stick) 450mm x 50m



Fresh cling refills - pack of 3 300mm x 300m



Aluminium foil refills:- pack of 3 300mm x 90m



All refills are supplied in individual tamper-proof cardboard boxes and shrink wrapped in 3's, for guaranteed hygiene!





#### **Speedwrap Dispenser**

Easy to load and use - refill instructions!



**1.** Remove the Speedwrap dispenser from all outer packaging and open the lid by rotating the circular lock anti-clockwise.



2. Open the front panel by pressing the two side catches found on either end of the Speedwrap and gently pull the front cover forward.



**3.** Insert your chosen Prowrap refill into the body of the machine. The plastic locator on the core of the refill roll fits into the matching locator inside the Speedwrap. The other end should be fully pushed down into the ribbed cradle.



**4.** Pull a length of material from the roll and hold in one hand. Ensure the material feeds through the two grippers freely as you close the front panel until you feel the catches 'clip' into place.



5. Pull the material length and press firmly on the top lid. The Speedwrap will cleanly cut the material ready for use.

#### FREE inside every Speedwrap box!

Handy peel and stick labels showing what's inside your dispenser at a glance.

Helps reduce risk of cross contamination and promotes best hygiene practise.







## Love food but hate waste?

- Using a Speedwrap dispenser is an easy way to reduce wasted cling, foil and parchment
- It's a refillable and reusable system
- It's a simple, quick and hygienic way to cut cling film, foil and parchment paper
- Cuts with a single press
- Covering food is a convenient, inexpensive and quick way to seal in flavour, moisture and freshness whilst keeping harmful bacteria out
- Helps keep your food fresher for longer





# May help to **improve your** hygiene rating.

 Speedwrap catering dispensers are more hygienic than traditional cutter boxes

PROWRAP

- Cutting cling, foil and parchments is simple, quick and hygienic
- The unit protects the roll inside from knocks and spills whilst helping to reduce the risk of bacteria and cross contamination
- Refills are supplied in individual tamper-proof cardboard boxes and shrink wrapped in 3's for guaranteed hygiene
- Easy to clean and store, using a Speedwrap dispenser may help to improve your FHR score



